

Your washing machine

Consignments - You have opted for a modern, high-quality device, complete with manufacturer's warranty. The washing machine is distributed by the manufacturer's authorised dealer. Each appliance which leaves our factory is inspected thoroughly to ensure that it functions properly and is in perfect condition.

Further information on our products, accessories, spare parts and services can be found in www.miele-international.com or contact our customer service centre.

Intended use

- For use in the household only.
- For washing machine-washable textiles and hand-washable wool in wash basins.
- Do not use for washing machine-washable items which are not suitable for use in washing machines.
- Do not use for washing machine-washable items which are not suitable for use in washing machines.
- Do not use for washing machine-washable items which are not suitable for use in washing machines.

Preparation

- Checking the machine** - Connect installation according to separate installation instructions.
- Insert mains plug** - Insert the mains plug into the socket.
- Turn on the tap** - Turn on the tap.

Washing

- Sorting and inserting the washing** - Sort laundry according to manufacturer's instructions.
- Add detergent and care product** - Add detergent and care product to the appropriate compartments.
- Setting programmes** - Select the programme.
- Select Start/Pause** - Press the Start/Pause button.

Switching off

- Turn off tap** - Turn off the tap.
- Remove the washing** - Remove the laundry.
- End of programme when ...** - Wait for the programme to end.
- Terminating the programme** - Press the Start/Pause button.
- Change programme if ...** - Press the Start/Pause button.
- Cancel Programme** - Press the Start/Pause button.

Individual settings

- Energy-saving** - Select the energy-saving mode.
- Temperature** - Select the temperature.
- Spin speed** - Select the spin speed.
- Water level** - Select the water level.
- Time delay** - Select the time delay.
- Start/Pause** - Press the Start/Pause button.

Important information

- Protecting the washing and the machine** - Use the correct washing agents.
- Washing with different degrees of soiling** - Sort laundry according to soiling degree.
- Energy-saving** - Select the energy-saving mode.
- Risk of scalding!** - Be careful of hot water.

Contents

Intended use	Page 1
Preparation	Page 2
Washing	Page 3-4
Switching off	Page 5
Individual settings	Page 6
Important information	Page 7
Options	Page 8
Delivery instructions	Page 9
Consignments	Page 10
What to do if ...	Page 11

Protection of the environment

Reduce the amount of washing for the programme. Wash normally soiled washing without prewash. The temperature in the machine may differ from the set temperature. The temperature in the machine may differ from the set temperature.

Preparation

Before using your washing machine for the first time

Sorting and inserting the washing

Follow manufacturer's care instructions. Sort laundry according to manufacturer's instructions. Do not use for washing machine-washable items which are not suitable for use in washing machines.

Add detergent and care product

Use the correct amount of detergent and care product. Do not use for washing machine-washable items which are not suitable for use in washing machines.

Setting programmes

Select the programme. Press the Start/Pause button.

Select Start/Pause

Press the Start/Pause button.

Washing

Do not touch the door handle during washing. The door is locked.

Switching off

Turn the programme selector to **OFF**.

Turn off tap

Turn off the tap.

Remove the washing

Remove the laundry.

End of programme when ...

Wait for the programme to end.

Terminating the programme

Press the Start/Pause button.

Change programme if ...

Press the Start/Pause button.

Cancel Programme

Press the Start/Pause button.

Individual settings

Energy-saving

Select the energy-saving mode.

Temperature

Select the temperature.

Spin speed

Select the spin speed.

Water level

Select the water level.

Time delay

Select the time delay.

Start/Pause

Press the Start/Pause button.

Important information

Protecting the washing and the machine

Use the correct washing agents. Follow manufacturer's instructions. Do not use for washing machine-washable items which are not suitable for use in washing machines.

Washing with different degrees of soiling

Sort laundry according to soiling degree. Do not use for washing machine-washable items which are not suitable for use in washing machines.

Energy-saving

Select the energy-saving mode. Do not use for washing machine-washable items which are not suitable for use in washing machines.

Risk of scalding!

Be careful of hot water. Do not use for washing machine-washable items which are not suitable for use in washing machines.

Your washing machine

Congratulations – You have opted for a modern, high-quality domestic appliance manufactured by NEFF. The washing machine is distinguished by its economical consumption of water and energy. Each appliance which leaves our factory is inspected thoroughly to ensure that it functions properly and is in perfect condition.

Further information on our products, accessories, spare parts and services can be found at: www.neff-international.com or contact our customer service centres.

Contents

	Page
Intended use.....	1
Programmes.....	1
Selecting and adjusting a programme.....	3
Washing.....	3/4
After washing.....	4
Individual settings.....	5
Important information.....	6
Overview of programmes.....	7
Safety instructions.....	8
Consumption values.....	8
Care.....	9
Information about the indicator lights.....	9
Maintenance.....	10
What to do if.....	11



Protection of the environment/Conservation tips

- Utilise the maximum amount of washing for the particular programme.
- Wash normally soiled washing without prewash.
- The selectable temperatures apply to the care labels on the textiles. The temperatures in the machine may deviate from this so that you get the optimum mix of energy-saving and washing results.
- Measure detergent according to the manufacturer's instructions and water hardness.
- If the washing is then dried in the tumble dryer, select spin speed according to the instructions of the dryer manufacturer.

Intended use

- for use in the household only,
- for washing machine-washable textiles and hand-washable wool in wash liquor,
- to be operated with cold drinking water and commercially available detergents and care products which are suitable for use in washing machines.



- Observe the safety instructions on page 8
- Do not leave children unattended near the washing machine!
- Children and un instructed persons must not use the washing machine!
- Keep pets away from the washing machine!
- Switch on washing machine only with base strip attached



Do not switch on the washing machine until you have read these instructions and the separate Installation/Maintenance instructions!

Programmes

Detailed overview of programmes → Page 7

Spin speed can be selected individually irrespective of the selected programme and programme progress.

Cottons	hard-wearing textiles
Cottons	hard-wearing textiles
Mix	different types of washing
Rinse	extra rinse with spin
Spin	washing washed by hand; extra spin with selectable spin speed
Drain	the rinsing water when Rinse Hold is activated (rinse stop = without final spin)
Wool	hand/machinewashable wool
Delicates	delicate washable textiles
Easy-Care	for easy-care textiles

Preparation



Correct installation according to separate installation instructions.



Checking the machine

- Never switch on a damaged machine!
- Inform your customer service!



Insert mains plug

- With dry hands only!
- Take hold of the plug only!



Turn on the tap




Dispenser II: Detergent for main wash, softener, bleach, stain remover

Dispenser : Fabric softener, starch

Dispenser I: Detergent for prewash

(* depending on model)



Before using your washing machine for the first time
wash once without any washing. → Page 9

Sorting and inserting the washing

Follow manufacturer's care information!
According to the information on the care labels.
According to type; colour; soiling and temperature.
Do not exceed maximum load. → Page 7

Follow important instructions! → Page 6

Insert large and small items of washing!
Close the washing machine door. Do not jam items of washing between the washing machine door and rubber seal.

Add detergent and care product

Dose according to:
Amount of washing, soiling, water hardness (available from your water utility company) and manufacturer's instructions.


Pour liquid detergent into corresponding dispenser and place in drum.
Caution when opening the detergent drawer while the appliance is running!

i Dilute viscous fabric softener and fabric conditioner with water.
Prevents blockage of the overflow.

Setting programmes

i Additional functions and spin speed
→ Individual settings, Page 5


Programme selector



Programme selector for switching the machine on and off and for selecting the programme. Can be rotated in either direction.

Select Start/Pause

Washing



Washing

Switching off

Turn the programme selector to **Off**.

Turn off tap

Not required for Aqua-Stop models.
→ Information, Installation Instructions

Remove the washing

Open washing machine door and remove washing.
If **Rinse Hold** (rinse stop = without final spin) active:
Set programme selector to **Drain** or **Spin**.
Select **Start/Pause**.

i – Remove any foreign objects – risk of rusting.
– Leave detergent drawer and door open so that residual water can evaporate.

End of programme when ...

... **Ready** is lit on the indicator light.

Terminating the programme

For programmes at high temperature:

– Cool washing: select **Rinse**.
– Select **Start/Pause**.

For programmes at low temperature:

– Select **Spin** or **Drain**.
– Select **Start/Pause**.

Change programme if ...

... you have mistakenly selected a wrong programme:

– Reselect programme.
– Select **Start/Pause**.
The new programme starts from the beginning.

Cancel Programme


– Select **Start/Pause**.
– If required, top up washing (do not leave door open for a long time – water from the washing could run out of the open door).
– Select **Start/Pause**.

Individual settings

Spin speed → depending on model

You can change the indicated spin speed or select **Rinse Hold** (rinse stop = without final spin cycle, washing remains in the water after the last rinse cycle). Effects dependent on the programme progress. The maximum selectable spin speed depends on the model and the set programme.

Additional functions → Overview of programmes, Page 7

Eco*  Energy-optimised washing by reducing the temperature while achieving a consistent washing result. The washing temperature is lower than the selected temperature. For special hygiene requirements, it is recommended that a higher temperature be selected.

Prewash For heavily soiled washing. Prewash at 30 °C.

Less Ironing Special spin sequence with subsequent fluffing. Gentle final spin at reduced spin speed. Residual moisture of the washing slightly increased.


Extra Rinse Additional rinse cycle. Longer programme duration. For areas with very soft water or for further improvement of the rinsing result.

Start/Pause

For starting or interrupting the programme.

Signal


1. Activate setting mode for signal volume




* Long signal - function on.
Short signal - function off.

Optional:


Blind mode *
ON-OFF



... Button signals



** If required, select repeatedly



5

Important information

Before using your washing machine for the first time

- Do not put any washing in the washing machine! Turn the tap on. Pour into dispenser II:
 - approx. **1 litre** of water,
 - detergent (dosage according to manufacturer's instructions for light soiling and according to degree of water hardness).
 - Set programme selector to **Easy-Care 60 °C** and select **Start/Pause**.
 - At the end of the programme set the programme selector to **Off**.



Protecting the washing and the machine

- When dosing all detergents, cleaning aids and cleaning agents, always follow the manufacturer's instructions.
- Empty pockets. Remove metal parts (paper clips, etc.).
- Wash delicates in the net/bag (tights, curtains, underwired bras).
- Close zips, button up covers.
- Brush sand out of pockets and collars.
- Remove curtain fittings or include in the net/bag.







Insert laundry

Insert large and small items of washing!
Do not jam items of washing between the washing machine door and rubber seal.



Washing with different degrees of soiling

- | | | |
|-------|---|---|
| Light |  | Wash new items separately.
Do not prewash. |
| Heavy |  | If required, pretreat stains. Select Eco*  additional function.
Load less washing. Prewash.
If required, pretreat stains. Select Eco*  additional function. |




Soaking

Load washing of the same colour.
Pour soaking agent/detergent into dispenser II according to the manufacturer's instructions. Set programme selector to **Cottons 30 °C** and select **Start/Pause**. After approx. 10 minutes select **Start/Pause** to stop the programme. After the required soaking time reselect **Start/Pause** if the programme is to be continued or change the programme.



Starching

Washing should not be treated with fabric softener.
Liquid starch can be used in all wash programmes. Pour starch into the fabric softener dispenser  according to manufacturer's specifications (if required clean beforehand).



Dyeing/Bleaching

Dye in household quantities only. Salt may attack stainless steel! Observe specifications of the dye manufacturer! Do **not** bleach washing in the washing machine!




Emergency release e.g. if power failure occurs

The programme continues running when the power supply is restored.
If the washing is still to be removed, the door can be opened as described below:



Risk of scalding!
Detergent solution and washing may be hot. If required, leave to cool down.
Do not reach into the drum in case it is still rotating.
Do not open the door if you can still see water through the glass.

1. Set programme selector to **Off**, pull out the mains plug.
2. Removing base strip → see separate installation instructions.
3. Drain the water. → Page 10
4. Pull down emergency release with a tool and release. Door can then be opened.
5. Attaching base strip → see separate installation instructions.



6

Programmes	°C	max.	Type	Additional functions; information
Cottons	20 - 90 °C			
Cottons	40, 60 °C	7 kg*	Hard-wearing textiles, heat-resistant textiles made of cotton or linen	Eco*
Easy-Care	30 - 60 °C	3,5 kg*	Easy-care textiles made of cotton, linen, synthetic fibres or blended fabrics	Eco*
Mix	30 °C		Textiles made of cotton or easy-care textiles	Eco*
Delicates	30 °C	2,0 kg	For delicate, washable textiles; e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. curtains)	Eco*
Wool	cold, 30 °C		Hand or machine-washable wool or rich-wool textiles	Eco*

Additional programmes

Rinse, Spin, Drain

i The programmes are time-controlled for lightly soiled textiles. If textiles are heavily soiled, reduce the load or select additional function, e.g. Eco*

When washing at maximum load using programmes marked with * always select Eco*

Irrespective of the type of washing, **Easy-Care 40 °C** at max. selectable spin speed is best suited as a **short programme**

Programmes without Prewash – pour detergent into dispenser II, programmes with Prewash – divide detergent between dispensers I and II.

9401 / 9000959481

NEFF GmbH
Carl-Wery-Str. 34
81739 München/Deutschland

W5420X1GB

! Safety instructions

- Read and follow the operating and installation instructions and all other information enclosed with the washing machine.
 - Retain documents for subsequent use.
- Risk of electric shock**
- Never pull out the mains plug by tugging the power cord!
 - Insert/pull out the mains plug with dry hands only.
- Danger to life**
- On redundant appliances:
- Pull out the mains plug!
 - Sever the power cord and discard together with the plug.
 - Destroy the lock on the washing-machine door. This will prevent children from locking themselves in and suffocating.
- Risk of suffocation**
- Keep packaging, plastic film and packaging parts out of the reach of children.
- Risk of poisoning**
- Keep detergents and care products out of the reach of children.
- Risk of explosion**
- Caused by detergents containing solvents, e.g. stain remover / items of washing pretreated with solvent naphtha may result in an explosion after being loaded into the washing machine. Before hand thoroughly rinse items of washing by hand.
- Risk of injury**
- Washing machine door may become very hot.
 - Caution when draining hot detergent solution.
 - Do not climb on the washing machine.
 - Do not lean on the open washing machine door.
 - Do not reach into the drum in case it is still rotating.

Consumption values

Programme	Additional function	Load	Current***	Water***	Programme duration***
Cottons 20 °C	-	7 kg	0,21 kWh	77 l	1¼ h
Cottons 40 °C*	Eco*	7 kg	0,78 kWh	77 l	2¼ h
Cottons 60 °C	-	7 kg	1,30 kWh	77 l	1¾ h
Cottons 90 °C	-	7 kg	2,26 kWh	90 l	2 h
Easy-Care 40 °C*	Eco*	3,5 kg	0,58 kWh	57 l	1¼ h
Delicates/Silk 30 °C	-	2,0 kg	0,17 kWh	30 l	¾ h
Wool 30 °C	-	2,0 kg	0,20 kWh	40 l	¾ h

* Programme setting for test according to currently valid European standard 60456. Information about comparability tests:
To test the test programmes, wash indicated load, with Eco*

Programme	Additional function	Load	Annual energy consumption	Annual water consumption
Cottons Eco	Eco*	7/3.5 kg	220 kWh	11000 l



** Programme setting for testing and energy labelling according to directive 2010/30/EU with cold water (15 °C).
*** The values deviate from the indicated values depending on water pressure, water hardness, water inlet temperature, room temperature, type and amount of washing and degree of soiling, utilised detergent, fluctuations in the mains voltage and selected additional functions.

Insert for liquid detergent depending on model

- Position insert for dosing liquid detergent:
- Completely remove detergent drawer. → *Page 10*
 - Push insert forwards.
- Do not use insert (push upwards):
- For gel-like detergents and washing powders,
 - For programmes with **Prewash**.



Care

-  – Risk of electric shock! Pull out the mains plug!
 – Risk of explosion! No solvents!



Machine housing, control panel


- Remove detergent residue immediately.
- Wipe with a soft, damp cloth.
- Do not clean the appliance with a water jet.

Clean the detergent drawer ...

... if it contains detergent or fabric softener residue.

1. Pull out, depress insert, take out drawer all the way.
2. Take out insert: using your finger, press insert upwards.
3. Clean detergent dispenser and insert with water and a brush and dry.
4. Attach insert and lock into position (push cylinder onto guide pin).
5. Slide in the detergent dispenser.



 Leave detergent drawer open so that residual water can evaporate.

Drum


















































































Leave washing machine door open so that the drum can dry out. Use chlorine-free cleaning agent, not steel wool.

Descaling No washing in the machine!

Not required if detergent dosed correctly. However, if this does occur, follow the instructions of the descaling agent manufacturer. Suitable descalers can be purchased on our website or from customer service.

Information about the indicator lights depending on model

A signal sounds and the indicator lamps for spin speed and status displays flash:

	Close the washing machine door properly; washing may be caught.		Turn on tap fully, supply hose kinked/jammed; clean filter → <i>Page 10</i> , water pressure too low.		Drain pump blocked; clean drain pump. → <i>Page 10</i>
					Drainage hose/outlet pipe blocked; clean drainage hose on the siphon. → <i>Page 10</i>
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					

Other displays: Switch off appliance, wait 5 seconds and switch on again. If the display is indicated again, call customer service. → *Installation Instructions*

9

Maintenance





- Risk of scalding! Allow detergent solution to cool down!
- Turn off the tap!



Detergent-solution pump

Set programme selector to **Off**, pull out the mains plug.

1. Take the drainage hose out of the holder. Remove sealing cap, allow detergent solution to flow out. Put the closing cap back on the hose.
2. Carefully unscrew the pump cover (residual water).
3. Clean the interior, pump cover thread and pump housing (fan impeller in the detergent-solution pump must rotate).
4. Reinsert and screw on pump cover. Handle is upright. Insert the drain hose into the holder.



To prevent unused detergent from flowing into the outlet during the next wash: Pour 1 litre of water into dispenser **II** and start the **Drain** programme.



Drainage hose on the siphon

Set programme selector to **Off**, pull out the mains plug.

1. Loosen hose clip, carefully remove drainage hose (residual water).
2. Clean drainage hose and siphon spigot.
3. Re-attach drainage hose and secure connection point with hose clip.



Filter in the water inlet hose

 **Risk of electric shock!**
Do not immerse Aqua-Stop safety device in water (contains electric valve).



Release water pressure in the supply hose:

1. Turn off the tap!
2. Select any programme (except **Spin/Drain**).
3. Select **Start/Pause**. Leave programme for approx. 40 seconds.
4. Turn the programme selector to **Off**. Pull out the mains plug!

Clean the filter:

5. Disconnect the hose from the water tap. Clean filter with small brush.

and/or for standard and Aqua-Secure models: Remove hose from the rear of the appliance. Take out filter with pliers and clean.



6. Connect the hose and check for leaks.

10

What to do if ...

- Water is running out.
 - Correctly attach/replace drainage hose.
 - Tighten screw-fitting on the supply hose.
 - Water not flowing in. Detergent not washed in.
 - **Start**/Pause not selected?
 - Tap not open?
 - Filter blocked? Clean the filter. → *Page 10*
 - Supply hose kinked or jammed?
 - Washing-machine door cannot be opened.
 - Safety function active. Stop programme? → *Page 4*
 - **Rinse Hold** (Rinse stop = without final spin) selected? → *Page 3, 4*
 - Can be opened via emergency release only? → *Page 6*
 - Programme does not start.
 - **Start**/Pause not selected?
 - Door closed?
 - Detergent solution is not drained.
 - **Rinse Hold** (Rinse stop = without final spin) selected? → *Page 3, 4*
 - Clean the drain pump. → *Page 10*
 - Clean outlet pipe and/or drainage hose.
 - Water not visible in the drum.
 - Not a fault – water below the visible area.
 - Spin result not satisfactory, washing wet/too damp:
 - Not a fault – unbalanced load detection system has stopped the spin cycle, washing unevenly distributed. Distribute small and large items of washing in the drum.
 - **Less Ironing** is selected? → *Page 5*
 - Too low speed selected? → *Page 5*
 - The programme duration changes during the wash cycle.
 - Not a fault – the programme sequence is optimised for the particular wash process. This may result in changes to the programme duration in the display field.
 - Spin cycle actuated several times.
 - Not a fault – unbalanced load detection system adjusts imbalance.
 - Residual water in the dispenser for care product ☼.
 - Not a fault – effect of the care product not impaired.
 - If required, clean insert. → *Page 9*
 - Odour formation in the washing machine.
 - Run **Cottons 90 °C** programme without washing. Use standard detergent.
 - Foam is coming out of the detergent drawer.
 - Too much detergent used?
 - Mix 1 tablespoon of fabric softener with ½ litre of water and pour into dispenser **II** (*not for outdoor, sports and down-filled textiles!*).
 - Reduce detergent dosage for the next wash cycle.
 - Loud noise formation, vibrations and "Wandering" during spin cycle.
 - Appliance feet fixed?
 - Secure appliance feet. → *Installation Instructions*
 - Transportation protection devices removed?
 - Remove transportation protection devices. → *Installation Instructions*
 - Noises during spin and drain cycles.
 - Clean the drain pump. → *Page 10*
 - Indicator lights do not function while the appliance is running.
 - Power failure?
 - Fuse tripped? Switch on/replace fuse.
 - If the fault occurs repeatedly, call customer service.
 - The programme takes longer than usual.
 - Not a fault – unbalanced load detection system adjusts imbalance by repeatedly distributing the washing.
 - Not a fault – foam detection system active – a rinse cycle is switched on.
 - Detergent residue on the washing.
 - Occasionally phosphate-free detergents contain water-insoluble residue.
 - Select **Rinse** or brush the laundry after washing.
 - In the pause status **Start**/**Pause** flashes very quickly and a signal sounds.
 - Water level too high. Washing cannot be reloaded. Immediately close washing machine door.
 - Select **Start** to continue the programme.
- If a fault cannot be rectified (switching the machine on and off) or a repair is required:
- Set programme selector to **Off** and pull out the mains plug.
 - Turn off the tap and call customer service. → *Installation Instructions*



en Instruction manual

WASHING
MACHINE

