

## Ardo washing machines Error Codes

Error code Error code interpretation Probable malfunction of the washing machine

E00, E01 Drain from washing machine

The filter of the filter of the washing machine.

E02 Incorrect drain / fill of water and spin

Incorrect drain hose position - system malfunction.

E03 There is no discharge of water from the tank or the drainage time has been exceeded (more than 3 minutes) A technical malfunction, which in any case should be addressed to the service center for household appliances maintenance

F2 Temperature sensor Problems in the temperature sensor, in the control module or in the heating element

F4 There is no water drain Problems in connecting the drain hose, malfunction in the drain pump. It is necessary to replace it.

F5 Simultaneous drain and set of water The drain hose is not properly connected, there are problems in the water supply filter.

F6, F6, F12 There was a water overflow in the tank of the washing machine. Malfunction of the module or motor.

F8 Excessive water level in the tank Problems in the water level sensor - problems with the solenoid valve.

F13, F14 Problems in the water level sensor - problems with the solenoid valve. Critical errors, inform about the malfunction of the electronic control module.