

## INDESIT Washing Machine Error Codes

### INDESIT

F01 - problems in the operation of the drive motor due to a short circuit in the control circuit.

F02 - there is no signal about the operation of the motor from the technogenerator to the electronic controller.

F03 - there are problems with the temperature sensor.

F04 - the machine signals a malfunction of the water level sensor.

F05 - problems with water drainage.

F06 - signal about a malfunction of buttons in the CM series in the Ariston Dialogic line.

F07 - the machine warns that the heating element is not immersed in water.

F08 - malfunction of the heating element.

F09 - electronic control malfunction.

F10 - error in the operation of the water level sensor.

F11 - there are problems in the operation of the drain pump.

F12 - problems in communication between the electronic controller and the display module.

F13 - failure in the drying operation (control network t0 is faulty).

F14 - failure in the drying (drying does not turn on).

F15 - failure in drying (drying does not turn off).

F17 - error in the operation of the lock (the door is not closed tightly).

F18 - microprocessor error.