

Error codes for household split systems

E1

Refrigerant circuit overpressure alarm

E2

Evaporator freezes

E3

Low system pressure

E4

High discharge temperature

E5

Overcurrent compressor

E6

Communication problem between indoor and outdoor units

E8

Indoor fan motor protection

F0

Air temperature sensor defective

F1

The evaporator temperature sensor is out of order

F2

The condenser temperature sensor is out of order

F3

The temperature sensor is out of order

F4

The temperature sensor is out of order